



Pos.	Description	Part-No.	Qty.
8a	support tube	see pos.8	1
8b	rod cover	see pos.8	1
8c	rebound rubber	see pos.8	1
8d	rebound spring guide3	see pos.8	1
8e	rebound spring 1	see pos.8	1
8f	rebound spring guide2	see pos.8	1
8g	rebound spring 2	see pos.8	1
8h	rebound spring guide1	see pos.8	1
8i	rebound spacer	see pos.8	1
8j	support plate	see pos.8	1
8k	support bolt	see pos.8	1
8l	air piston	see pos.8	1
8m	air seal	see pos.8	1
8n	air cylinder	see pos.8	1
9	RL-cartridge	FUN021-20	1
9a	RL-cartridge part "a"	see pos.9	1
9b	RL-cartridge part "b"	see pos.9	1
9c	U-Packing	FAA213	1
9d	RL-cartridge part "d"	see pos.9	1
9e	RL-cartridge part "e"	see pos.9	1
9f	RL-cartridge part "f"	see pos.9	1
9g	RL-cartridge part "g"	see pos.9	1
9h	RL-cartridge part "h"	see pos.9	1
9i	RL-cartridge part "i"	see pos.9	1
9j	RL-cartridge part "j"	see pos.9	1
9k	RL-cartridge part "k"	see pos.9	1
9l	RL-cartridge part "l"	see pos.9	1
9m	RL-cartridge part "m"	see pos.9	1
9n	RL-cartridge part "n"	see pos.9	1
10	air cap assembly	FKE075	1
10a	top washer	see pos.10	1
10b	o-ring	see pos.10	1
10c	o-ring	see pos.10	1
10d	air cap	see pos.10	1
10e	valve core	see pos.10	1
10f	valve cap	see pos.10	1
11	RL remote assembly	FKE112	1
11a	RL remote ass'y - part a	see pos.11	1
11b	RL remote ass'y - part b	see pos.11	1
12	RL remote Lever ass'y	SL6SC-RLO	1
12a	RL remote Lever - part a	see pos.12	1
12b	RL remote Lever - part b	see pos.12	1
12c	RL remote Lever - part c	see pos.12	1
12d	RL remote Lever - part d	see pos.12	1
12e	RL remote Lever - part e	see pos.12	1
12f	RL remote Lever - part f	see pos.12	1
1	bottom case fixing kit	FKA044	1
1a	fixing nut	see pos. 1	2
1b	washer	see pos. 1	2
2	bottom case assembly	FKE153	1
3	oil wiper	FAA207	2
4	dust seal	FAA169	2
5	bottom bumper	FEP233-10	1
6	upper assembly	FKE154-00	1
7	cylinder guide	FEE554	1
8	air semi cartridge	FKE146	1