


SF SUNTOUR

SF11-XCR-DS-LOD



NO.	PARTS CODE	PARTS NAME	80	100	120	QT
1	FKE237-20	BOTTOM CASE ASSY	*	*	*	1
1b	FEE449	SLIDER SLEEVES	*	*	*	2
1c	FAA070-10	DUST SEAL	*	*	*	2
2	FKE216-21	UPPER ASSY	*	*		1
	FKE216-31				*	1
3	FKE009-13	ADJUSTER ASSY	*	*	*	1
4	FEE763	LOCK OUT KNOB	*	*	*	1
5	FEE764	ADJUST KNOB	*	*	*	1
6	FEE256-20	ADJUST CORE	*	*	*	1
7	FAA072	O RING	*	*	*	1
8	FEE767-30	ADJUST CAP	*	*	*	1
9	FUN042-10	LOD UNIT	*	*	*	1
10	FKE333-00	MAIN SPRING ASSY	*			1
	FKE332-00			*		1
	FKE331-00				*	1
11	FEP531-00	DAMPER	*	*	*	1
12	FEE434-40	SPRING GUIDE	*	*	*	2
13	FEE798	SUPPORT TUBE	*	*	*	1
14	FEP189-20	REBOUND SPRING	*	*	*	1
15	FEE937	REBOUND SPRING GUIDE	*	*	*	1
16	FEE286-10	REBOUND SPACER	*			2
				*		1
17	FEP053-10	REBOUND RUBBER	*	*	*	1
18	FEE799	BOTTOM STOPPER	*	*	*	1
19	FKA044	FIXING BOLT SET	*	*	*	1
20	FEE797	CABLE GUIDE	*	*	*	1
21	FSB153	CABLE FIXING BOLT	*	*	*	1