



| NO. | PARTS CODE | PARTS NAME | 100 | 120 | QT |
|-----|------------|------------------------|-----|-----|----|
| 1 | FKE379-70 | UPPER ASSY | * | * | 1 |
| 2 | FKE426 | BOTTOM CASE ASSY | * | * | 1 |
| 2d | FAA169-20 | DUST SEAL | * | * | 2 |
| 3 | FKA044 | FIXING BOLT SET | * | * | 1 |
| 4 | FAA150 | VALVE CAP | * | * | 1 |
| 5 | FSN017-01 | FIXING NUT | * | * | 1 |
| 6 | FEE248-20 | BOTTOM STOPPER | * | * | 1 |
| 7 | FEP052-10 | REBOUND RUBBER | * | * | 1 |
| 8 | FEE555-20 | REBOUND SPRING GUIDE 3 | * | * | 1 |
| 9 | FEP304 | REBOUND SPRING 1 | * | * | 1 |
| 10 | FEE555-10 | REBOUND SPRING GUIDE 2 | * | * | 1 |
| 11 | FEP305 | REBOUND SPRING 2 | * | * | 1 |
| 12 | FEE555-00 | REBOUND SPRING GUIDE 1 | * | * | 1 |
| 13 | FEE048-91 | SUPPORT TUBE | * | * | 1 |
| 14 | FEE247 | REBOUND SPACER | * | * | 1 |
| 15 | FEE047 | SUPPORT PLATE | * | * | 1 |
| 16 | FSB044 | SUPPORT BOLT | * | * | 1 |
| 17 | FEE261-20 | DAMPER CAP | * | * | 1 |
| 18 | FUN081-10 | RL-Air UNIT | * | * | 1 |
| 19 | FKE310-20 | RL COVER ASSY | * | * | 1 |
| 19a | FEE418-01 | FIX CAP | * | * | 1 |
| 19h | FEE939 | RL COVER | * | * | 1 |
| 20 | SL9SC-RLO | REMOTE LEVER ASSY | * | * | 1 |
| 21 | FSS041 | E RING | * | * | 1 |