


# SR SUNTOUR

RS16-DUAIR RC

216-63

Date	2015.06.18	Version	1
Amended			



20	O RING	RAA081	4	4	4	4
19	AL BUSHING	REE089	1	1	1	1
		REE089	1	1	1	1
		REE088	1	1	1	1
		REE088	1	1	1	1
18	AL BUSHING	RAA080	2	2	2	2
		RAA080	2	2	2	2
17	DU	REE074	2	2	2	2
16	O RING	RAA100	1	1	1	1
15	GAS CYLINDER ASSEMBLY	RBA216-10XL				1
		RBA216-10L			1	
		RBA216-10M		1		
		RBA216-10S	1			
14	O RING	FAA352	1	1	1	1
13	AIR CAP	RAA102	1	1	1	1
12	O RING	FAA140	1	1	1	1
11	AIR VALVE	FAA170	1	1	1	1
10	X RING	RAA046	1	1	1	1
9	FLOATING PISTON	REE066	1	1	1	1
8	MAIN BODY	RLB069-1	1	1	1	1
7	MAIN SPINDLE ASSEMBLY	RBA202-10	1	1	1	1
6	SCREW	PSB103	1	1	1	1
5	STEEL BALL	DS0001	1	1	1	1
4	SUPPORT SET ASSEMBLY	RBA201	1	1	1	1
3	O RING	RAA052	1	1	1	1
2	WASHER	RSW073	1	1	1	1
1	TOP ASSEMBLY	RBA200-20	1	1	1	1
NO.	DESCRIPTION	SR CODE	S	M	L	XL